

# BODY WORN CAMERA User Manual



## Safety Instruction

These instructions are intended to ensure that user can use our product correctly to avoid danger or property loss.

**⚠️ Cautions:** Injury or equipment damage may occur if any of cautions are neglected.

- Proper configuration of all passwords are the responsibility of the installer and/or end-user.
- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region.
- Input voltage should meet both the Safety Extra Low Voltage and the Limited Power Source with 5V DC.
- Please make sure that the plug is firmly connected to the power socket.
- If smoke, odor or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.

### Preventive and Cautionary Tips

Before operating your device, please be advised of the following tips:

- Do not store the product in high-temperature or damp environment, and do not expose it to high electromagnetic radiation.
- If the product does not function properly, please contact your dealer. Do not disassemble the product for repair or maintenance by yourself.
- Only use the battery, power adapter and accessories provided by the manufacturer.
- Consult the authorized dealer for any question and request for product using.

## Chapter 1 Introduction

Body-worn camera is the wearable camera incorporating an audio and video recording. This camera is designed for the use in law enforcement, and security activities to record the truth that agencies need to build transparency and accountability with the public.

### 1.1 Overview



Table 1.1 Buttons

Button	Description
Video	(1) Press it to start/end video recording. (2) Hold it for 3 seconds to activate pre-recording.
Snapshot	Press it to shoot a still photo.
Tag	(1) Press it to mark evidence with important tag. (2) Hold it for 3 seconds to activate LED white light.
Audio	Press it to start/end audio recording.
Power	Hold it for 3 seconds to power on/off.
Menu	Access to menu mode.
Confirm	(1) Confirm your option. (2) Activate IR light if IR light is in manual mode.

Table 1.2 LED Color

Mode	LED Indicator
Video Recording	Blinking Red
Audio Recording	Blinking Yellow
Standby	Solid Green
Charging	Solid Red & Solid Green

## 1.2 Mounting Clip Installation

The mounting clip is used for fixing the Body-worn camera to the uniform.

### Installation Step:

Push the clip onto the top of the mounting slot according to below instruction, slide the clip to the correct position, a click sound will be heard when it's done.



## 1.3 Charging

### Power Charger Specification:

Input: 100 to 240 V AC, 50/60 Hz. Output: 5 V/2.0 A.

“Low battery” shown if insufficient power, please connect Body-worn Camera to the charger with USB cable.

### Steps:

- Open the cover of USB.
- Connect Body-worn Camera to the charger with USB cable.

# Chapter 2 Operation

## 2.1 Power-on/off

Turn on the device by holding the Power Button for three seconds, when you hear a sound notification, it means the Body-worn camera starts up successfully. Hold the Power Button for three seconds again to power off.

## 2.2 Menu

After the Body-worn camera starts up, it enters into the preview mode automatically. Press the Menu Button to enter into menu mode.

## 2.3 Snapshot

You can take pictures of the crime scenes or other situations in using Body-worn Camera.

### Step:

Press Snapshot Button to take a picture.

## 2.4 Video Recording

Record the video in crime scenes or other situations.

### Steps:

- Press the Video Button to start recording, the LED indicator starts flashing in red.
- Optionally, during the video recording, you can press the Snapshot Button to capture current live view image. Or you can press the Important Tag Button to tag the video as an “IMPORTANT EVIDENCE”.
- Press the Video button again to end recording.

## 2.5 One Button Recording

Activate camera into video recording rapidly when the camera is power off.

**Step:** Hold the Video button for 3 seconds to turn on and start recording automatically.

## 2.6 Audio Recording

You can record the audio in crime scenes or other situations.

### Steps:

- Press the Audio button to start recording, the LED indicator starts flashing in yellow.
- Press the Audio button again to end recording.

## 2.7 Playback

Press Menu to enter into Menu Mode - Playback - Video/Audio/Photo.

### Notes:

You can fast forward or rewind with left/right button.

## 2.8 Eco Mode

The camera will be power off automatically when there's no operation. You can turn off Eco Mode and keep the camera in standby mode.

### Steps:

Menu Mode - System - Auto Shutdown - Off.

## 2.9 Stealth Mode

For some situations, you may wish to turn off the LED lights, sounds (audio prompts) on your camera. Turning off all the indicators and notifications is also known as stealth mode.

### Steps:

Menu Mode - General - Stealth Mode- On.

# Warranty Card

Product Name	
Purchase Date	
Description	
Name	
Mobile	
Email	
Address	